



Intermediate Housing KS

* not illustrated

Item	Description	NO.
1*	Intermediate Housing KS complete	3.10.30
2	stud bolt M 12 X 26	1.10.04
3	screw adapter	3.10.07
4	gasket ring A 24 X 30 (copper)	3.10.08
5	cover plate	3.10.12
6	gasket	3.10.13
7	stud bolt M 12 X 30	for 3.10.22
8	hexagon nut M 12	1.10.05
9	screw plug	3.10.16
10	gasket ring A 35 X 41 (copper)	3.10.17
11	screw plug	3.11.07
12	gasket ring A 14 X 18 (copper)	3.11.08
13	intermediate housing with all stud bolts	3.10.22
14	cover plate	3.10.23
15	gasket	3.10.24
16	hexagon screw M 8 X 20	1.11.03
17	housing gasket	3.10.02
18	hexagon screw M 12 X 40	3.10.05
19	hexagon screw M 12 X 45	3.10.19
(8)	hexagon nut M 12	1.10.05
20	oli sump drain pipe complete with items.21 a. 22	3.10.20
21	union nut M 16 X 1,5	for 3.10.20
22	union nipple 6 X 8	for 3.10.20
23	drain cock AM 14 X 1,5	3.10.21
24*	Oil Float Assembly	3.11.00
25	float needle with protecting cap	3.11.01
26	float needle guide	3.11.02
27	gasket ring	3.11.03
28	cork float	3.11.04
29	ring disk	3.11.05
30	split pin 1 X 15	3.11.06
32	lubricating oil connection piece	1.16.01
33	hexagon nut M 12 X 1,5	1.16.02
34	ring disk 21 X 35 X 3	1.16.03
35	rubber seal o-ring	1.16.04
36	gasket ring	1.16.06
37*	Cooling Water Inletting complete	3.13.10



Intermediate Housing KS

* not illustrated

Item	Description	NO.
38	cooling water inert fitting	3.13.11
39	hexagon nut M 40 X 1,5	3.13.12
40	ring disk	3.13.13
41	gasket ring A 30 X 36 (copper)	1.10.07
42	rubber seal o-ring	5.14.14
43	starting latch unit complete	14.20.50
44	gasket	14.20.02
45	cylindrical pin 6 X 20	14.20.05
46	lubricating oil pump complete	13.10.00
47	gasket	13.10.03
48	countersunk screw M 6 X 50	13.10.06
49	lubricating oil pipe fittings	see 13.00.00
50	cooling water pipe from compressor stage 1	see 12.91.62

